

Function/Channel/Dimmer

**FRONT OF HOUSE**

Stars	SL Stage	Step Wash	J	E	I	D	Front Wash	C	H	Front Wash	B	G	A	F	Step Wash	Flags	SR Stage																
11	74	52	10	05	09	04	51	03	08	51	02	07	01	06	52	12	73																
1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13	14	14	15	15	16	16	17	17	18

Function/Channel/Dimmer

**STAGE ELECTRIC # 1**

	Stage Blues	C Side	W Side		O	Bl	Am	Rd	B/D	N	Bl	Rd	B/D		M	B/D		Am	L	B/D	Bl	Am	Rd	K			C Side	W Side	
	24	64	70		17	27	87	39	76	16	26	38	77		15	77		86	14	76	25	85	37	13			61	67	
19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48

Function/Channel/Dimmer

**DOWNSTAGE FLOOR POCKETS**

GOBO	GOBO	GOBO
55	53	54
120	119	118

GOBO	GOBO	GOBO
54	53	55
111	110	109

Function/Channel/Dimmer

**STAGE ELECTRIC # 2**

	C Side	W Side			T	Bl	Am	Rd	B/D	S	Bl		Rd	B/D	R	B/D		Am	Q	B/D		Am	Bl	P	Rd		C Side	W Side	
	71	65			22	30	90	42	78	21	29		41	79	20	79		89	19	78		88	28	18	40		62	68	
49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78

Function/Channel/Dimmer

**MIDSTAGE AND UPSTAGE FLOOR POCKETS**

GOBO	GOBO	GOBO			X
56	57	58			X
123	122	121	124	125	126

					GOBO
					56
117	116	115	114	113	112

Function/Channel/Dimmer

**STAGE ELECTRIC # 3**

C Side	W Side	B/D			Rd	Am	Bl	Rd	Am	Bl												Rd	Am	Bl		B/D	C Side	W Side
72	66	80			44	92	32	45	93	33												43	91	31		81	63	69
79	80	81		83	84	85	86	87	88	89												102	103	104		106	107	108

Function/Channel/Dimmer

**STAGE ELECTRIC # 4**

			Gobo								RdC	LvC	BIC	GrC	RdC	LvC	BIC	GrC	RdC	LvC	BIC	GrC					Gobo		
			59								48	96	36	84	47	95	35	83	46	94	34	82				59			
			82								90	91	92	93	94	95	96	97	98	99	100	101				105			