

Front of House

Function	Stars	SL side	Step Wash	J	E	I	D	Front Cool	C	H	Front Warm	B	G	A	F	Center Ex.	SR Side	Flags
Channel	59	22	55	10	5	9	4	42	3	8	41	2	7	1	6	56	21	60
Dimmer	1	2/2	3/3	4/4	5/5	6/6	7/7	8/8	9/9	10/10	11/11	12/12	13/13	14/14	15/15	16/16	17/1	18
Instrument	S4	LEKO	S4	S4(x2)	S4(x2)	S4(x2)	S4(x2)	S4(x3)	S4(x2)	S4(x2)	S4(x3)	S4(x2)	S4(x2)	S4(x2)	S4(x2)	FN8(x2)	LEKO	S4(x2)

Stage Left Downstage Floor Pocket

Stage Right Downstage Floor Pocket

Function	Bottom Boom	Middle Boom	Top Boom	Function	Bottom Boom	Middle Boom	Top Boom
Channel	38	39	40	Channel	35	36	37
Dimmer	120	119	118	Dimmer	109	110	111
Instrument	S4	S4	S4	S4	S4	S4	S4

Stage Left Midstage Floor Pocket

Stage Right Midstage Floor Pocket

Function	Open Dimmer	Open Dimmer	Open Dimmer	Function	Open Dimmer	Open Dimmer	Open Dimmer

Stage Left Upstage Floor Pocket

Stage Right Upstage Floor Pocket

Function	Open Dimmer	Open Dimmer	Footlight Power	Function	Open Dimmer	Open Dimmer	Footlight Power

Footlights

Function	SL 15 Cyc Light	SL 14 Cyc Light	SL 13 Cyc Light	SL 12 Cyc Light	SL 11 Cyc Light	CS 10 Cyc Light	CS 9 Cyc Light	CS 8 Cyc Light	CS 7 Cyc Light	CS 6 Cyc Light	SR 5 Cyc Light	SR 4 Cyc Light	SR 3 Cyc Light	SR 2 Cyc Light	SR 1 Cyc Light
Channel	137	136	135	134	133	132	131	130	129	128	127	126	125	124	123
Dimmer	32	32	32	32	32	32	32	34	34	34	34	34	34	34	34
DMX Address	469-478	459-468	449-458	439-448	429-438	419-428	409-418	399-408	389-398	379-388	369-378	359-368	349-358	339-348	329-338
Instrument	Colordash	Colordash	Colordash	Colordash	Colordash	Colordash	Colordash	Colordash	Colordash	Colordash	Colordash	Colordash	Colordash	Colordash	Colordash

Misc:

Function	House Lights	Isle/Lobby Lights	1E-2E Hard Power	3E-4E Hard Power
Channel	200	201	202	203
Dimmer			B12-23	B24-39
DMX Address (UNIVERSE 4)	1-7+9	8+10	11-23	24-39

Abbreviation	S4	LEKO	FN#	LG	CO	White Back	Blue Back	Green Back
Full Term	Source 4	Non-Source 4 Leko Light	Fresnel 8" or 6"	Chauvet Legend	Colorado	1st DMX Universe	2nd DMX Universe	3rd DMX Universe